

## NO-TILL! MULCH-TILL! CONVENTIONAL!

Match KINZE® row unit attachments to your system to create the ideal growing environment for optimum emergence in a wide range of cropping practices and residue management systems.



**3000 Pull Type 6 Row N (30")**  
with Interplant® Package and  
Row Unit Mounted No Till Coulters



**Row Unit Mounted No Till Coulters** — available on standard and push row units — feature welded fork design with four blade depth settings in 1/2" increments to compensate for blade wear. Sealed double-row ball bearings provide long life. The KINZE® Row Unit Mounted Coulters attachment also includes two extra springs for added down force.



**Coulters Mounted Residue Wheel Attachments** have free-floating 12" diameter wheels with 12 curved tines in interlocked or staggered mountings; eleven depth settings in 1/4" increments.



**16" Diameter Coulters Blades**  
Top-quality. Select 1" bubbled, 3/4"-13 fluted or 1"-8 fluted designs.

## ADDITIONAL ROW UNIT MOUNTED ATTACHMENTS



**RESIDUE WHEEL ATTACHMENTS**  
Ideal for mulch-till. 12" diameter wheel; 12 curved tines. 3-position mounting varies aggressiveness. Spring-loaded parallel linkage. Cast iron hub.



**ROW UNIT MOUNTED DISC FURROWERS** Notched or solid 12" diameter blades clear clods and residue for a residue-free seed bed. Cast iron hubs; sealed bearings.



**BED LEVELERS**  
"V" blades (6" x 17") remove a top layer of dry soil or clods to create a level 16" planting surface in light, well-tilled conditions. (For 36" or wider rows only.)



**DUAL ROW UNIT GAUGE WHEELS**  
Designed for highly tilled soils where additional flotation is required. Includes all mounting hardware. (For 36" or wider rows only.)

## FRAME MOUNTED NO TILL COULTERS

Planting in rocky ground or severe no-till conditions? KINZE® Frame Mounted Coulters are designed to apply needed spring down pressure on the coulters for maximum penetration while exerting less shock load on the row unit.

Choose 1" bubbled, 3/4"-13 fluted or 1"-8 fluted blades. The Frame Mounted No Till Coulters is clamped to the existing row unit support plate which, in turn, mounts to the toolbar.

Coulters blades are mounted on cast iron hubs with sealed bearings. Blade depth settings are adjustable to compensate for blade wear or when deeper penetration is desired.

Two 2 3/8" adjustable coil springs allow you to apply up to 500 lbs of down force.

Also available, free-floating residue wheel attachment, complete with weed guard and eleven 1/4" incremental depth settings.

